

17/SK0305 21_01

THE INSTA-GLAMERS PRIMER – TENTATIVE FORMULATION

INGREDIENTES	INCI-Name	%	FORNECEDORES
FASE A			
Água Deionizada	Aqua	q.s.p.100	
SymSave® H	Hydroxyacetophenone	0,50	Symrise
Aristoflex Velvet	Polyacrylate Crosspolymer-11	0,40	Clariant
FASE B			
Hydrolite® 5 green	Pentylene Glycol	2,00	Symrise
SymMollient® W/S	Trideceth-9, PEG-5 Isononanoate, Water (Aqua)	2,00	Symrise
SymDiol® 68	1,2-Hexanediol, Caprylyl Glycol	0,50	Symrise
Fragrância (943163)	Parfum	0,30	Symrise
Solubilizer (611674)	PEG-40 Hydrogenated Castor Oil, Trideceth-9, Water (Aqua)	1,00	Symrise
FASE C			
Actipone® Alpha Cranberry CA (461359)	Glycerin, Vaccinium Macrocarpon (Cranberry) Fruit Extract, Pentylene Glycol, Glyceryl Caprylate	1,00	Symrise
RetinoPeptide 189	Glycerin, Pentylene Glycol, Water (Aqua), Myristoyl Nonapeptide-3	5,00	Symrise
SymLift®	Water (Aqua), Trehalose, Glycerin, Pentylene Glycol, Beta-Glucan, Hordeum Vulgare Seed Extract, Sodium Hyaluronate, 1,2-Hexanediol, Caprylyl Glycol	5,00	Symrise
Timiron Splendid Gold	Mica (and) Titanium Dioxide	1,30	Merck
Mystic Fuchsia	Mica (and) Titanium Dioxide (and) Carmine	0,40	Look Química
Micapearl Iris Fine Gold	Mica	1,00	Maxxi Química
Flamenco Super Violet	Mica (and) Titanium Dioxide	0,40	Basf
Mica Glamour Shimmer Gold G2605	Mica	0,10	Look Química

PROCEDIMENTO

1. Em um béquer, pesar os itens da FASE A e homogeneizar até completa solubilização dos itens e dispersão do polímero. Resfriar.
2. Em outro béquer pesar a FASE B e homogeneizar em UltraTurrax para que o titânio esteja bem disperso.
3. Verter a FASE B sobre FASE A e homogeneizar em agitador mecânico à 400 RPM para evitar a formação de bolhas.
4. Adicionar os itens da FASE C, um-a-um, e homogeneizar.

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of our products are beyond our control. Symrise makes no warranties, either expressed or implied, as to the accuracy or appropriateness of this data. Symrise expressly disclaims any implied warranty of fitness for a particular use. We recommend that prospective users determine for themselves the suitability of Symrise materials and suggestions for any use prior to their adoption. We also recommend that prospective users, as required, obtain approval from appropriate regulatory authorities. Suggestions for uses of our products or the inclusion of descriptive material from patents and the citation of specific patents in this publication should not be understood as recommending the use of our products in violation of any patent or as a permission or licence to use any patent of Symrise.

Symrise Aromas e Fragrâncias Ltda
Scent & Care Division

Estrada do Capuava, 1000 - CEP: 06715-725 – Cotia - São Paulo – Brazil
Phone (55 11) 4615- 7421 - (55 11) 4615- 7482
www.symrise.com

17/SK0305 21_01

THE INSTA-GLAMERS PRIMER – TENTATIVE FORMULATION

5. Se necessário adicionar a NaOH (sol 50%) para ajustar pH (5,50 – 6,50) e homogeneizar em agitador mecânico.

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of our products are beyond our control. Symrise makes no warranties, either expressed or implied, as to the accuracy or appropriateness of this data. Symrise expressly disclaims any implied warranty of fitness for a particular use. We recommend that prospective users determine for themselves the suitability of Symrise materials and suggestions for any use prior to their adoption. We also recommend that prospective users, as required, obtain approval from appropriate regulatory authorities. Suggestions for uses of our products or the inclusion of descriptive material from patents and the citation of specific patents in this publication should not be understood as recommending the use of our products in violation of any patent or as a permission or licence to use any patent of Symrise.

Symrise Aromas e Fragrâncias Ltda
Scent & Care Division

Estrada do Capuava, 1000 - CEP: 06715-725 – Cotia - São Paulo – Brazil
Phone (55 11) 4615- 7421 - (55 11) 4615- 7482

www.symrise.com