

## 17/SK0210 23\_01 CHANTILLY FACE BODY– TENTATIVE FORMULATION

INGREDIENTES	INCI-Name	%	FORNECEDORES
<b>FASE A</b>			
Emulsiphos® F	Potassium Cetyl Phosphate, Hydrogenated Palm Glycerides	2,50	Symrise
Alkonat 1898	Stearyl Alcohol	8,00	BASF
SymMollient® S green	Cetearyl Nonanoate	2,50	Symrise
SymMollient® PDCC	Propanediol Dicaprylate/Caprate	2,00	Symrise
DL-Alpha Tocopherol	Tocopherol	0,50	/
<b>FASE B</b>			
Água deionizada	Water (Aqua)	q.s.p 100	/
Gluconato de Sódio	Sodium Gluconate	0,10	/
SymSave ® H	Hydroxyacetophenone	0,50	Symrise
Hydrolite® 6 green	1,2-Hexanediol	0,50	Symrise
Hydrolite® 5 green	Pentylene Glycol	5,00	Symrise
SymSitive® 1609	Pentylene Glycol, 4-t-Butylcyclohexanol	3,00	Symrise
Makimousse 12	Sodium Polyacrylate Starch	1,50	Kobo
<b>FASE C</b>			
Farmal CS 3400	Corn Starch	1,00	Ingredion
SymReboot™ L19	Maltodextrin, Lactobacillus Ferment	0,50	Symrise
SymRelief® 100	Bisabolol, Zingiber Officinale (Ginger) Root Extract	0,10	Symrise
Actipone® Mango Hyper GW	Water (Aqua), Glycerin, Mangifera Indica (Mango) Fruit Extract	1,00	Symrise
Fragrância QNT11075AA	Parfum	0,30	Symrise
Food Clor Tartrazine 85% E102 C.I 19140 ( sol. 0,50%)	Water (Aqua), C.I 19140	2,00	Symrise
Food Color Azorubin 85% E 122 C.I 14720 (sol. 0,50%)	Water (Aqua), C.I 14720	0,20	Symrise

### PROCEDIMENTO

1. Em um béquer, pesar os itens da FASE A, aquecer até total fusão dos ingredientes a 75°C e homogeneizar.

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of our products are beyond our control. Symrise makes no warranties, either expressed or implied, as to the accuracy or appropriateness of this data. Symrise expressly disclaims any implied warranty of fitness for a particular use. We recommend that prospective users determine for themselves the suitability of Symrise materials and suggestions for any use prior to their adoption. We also recommend that prospective users, as required, obtain approval from appropriate regulatory authorities. Suggestions for uses of our products or the inclusion of descriptive material from patents and the citation of specific patents in this publication should not be understood as recommending the use of our products in violation of any patent or as a permission or license to use any patent of Symrise.

## 17/SK0210 23\_01

### CHANTILLY FACE BODY– TENTATIVE FORMULATION

---

2. Em outro béquer pesar os itens da FASE B (com exceção ao Makimousse 12 e Hydrolite® 5 green), aquecer até 75°C e homogeneizar. Adicionar sobre a FASE B o Makimousse 12 pré-misturado ao Hydrolite® 5 green em agitação, e dispersar completamente o polímero em agitador mecânico à 1500 RPM.
3. Verter a FASE B sobre a FASE A em agitador mecânico à 1500 RPM, mantendo em agitação por 5 minutos. Após, diminuir rotação para 600 RPM.
4. Deixar a fórmula resfriar sob agitação.
5. Quando a fase principal estiver abaixo de 45°C, adicionar os itens da FASE C um-a-um e homogeneizar.
6. Se necessário, ajustar pH para faixa de 4,50 – 5,50.

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of our products are beyond our control. Symrise makes no warranties, either expressed or implied, as to the accuracy or appropriateness of this data. Symrise expressly disclaims any implied warranty of fitness for a particular use. We recommend that prospective users determine for themselves the suitability of Symrise materials and suggestions for any use prior to their adoption. We also recommend that prospective users, as required, obtain approval from appropriate regulatory authorities. Suggestions for uses of our products or the inclusion of descriptive material from patents and the citation of specific patents in this publication should not be understood as recommending the use of our products in violation of any patent or as a permission or license to use any patent of Symrise.

**Symrise Aromas e Fragrâncias Ltda**  
**Scent & Care Division**

Estrada do Capuava, 1000 - CEP: 06715-725 – Cotia - São Paulo – Brazil  
Phone (55 11) 4615- 6900 - (55 11) 4615- 7469  
[www.symrise.com](http://www.symrise.com)